

GET IT RIGHT

installation guide

let's make everyone happy and get it right the 1st time

## URBAN WOODS COMPANY

installation guide

"DO IT RIGHT OR DON'T DO IT AT ALL"

**specifying:** see our "spec it right" guide

**acclimation:** we recommend the material be placed in the space 3-5 days before installation with the HVAC system running to ensure proper conditions; do not install the material until it has had time to adjust to the relative humidity and temperature of the space.

**substrate:** plywood or OSB substrate material 1/4" to 1/2" thick; substrate must be smooth, dry and mostly straight; it should be painted black to hide any imperfections in the wood

**application:** in most cases, the wood should be surface nailed using 1-3/4" long 16 gauge brad nails

**seams:** recommended random joint seam locations for the most natural appearance

**finish:** unless requested otherwise, all material is sent with our eco-friendly finish pre-applied

**URBAN WOODS CO**

URBANWOODSCOMPANY.COM

2229 SANTA ANNA AVE . DALLAS, TX 75228

2 1 4 . 9 5 4 . 7 0 3 0

SAMPLES ARE REPRESENTATIONAL OF FULL RANGE OF COLOR, TEXTURE, AND VARIATIONS. BY THEIR NATURE, EACH RECLAIMED WOOD BOARD IS ONE-OF-A-KIND AND CAN POSSESS SOME OR ALL OF THE AGED CHARACTERISTICS EXPECTED. VARIATION IS TO BE EXPECTED.